



Via monte Nero, 40/B - 21049 TRADATE (VA) ITALY

Phone: +39 (0)331841070 Fax:+39 (0)331841950 - e-mail:datexel@datexel.it - www.datexel.it

FEATURES

- PROTECTION MODE: II 1 G Ex ia IIC certified in according to the Directive ATEX 94/9/EC
- Applicable in zones with explosion risk (ZONE 0)
- Configurable input for RTD, mV, Tc, Resistance and Potentiometer
- 4 ÷ 20 mA configurable output on current loop
- Configurable by Personal Computer, on-field reconfigurable
- High accuracy
- EMC compliant CE mark
- Suitable for DIN rail mounting in compliance with EN-50022 and EN50035

Intrinsically safe two wire transmitter

DAT 2015 IS DAT 2015 IS / HT







GENERAL DESCRIPTION

The isolated transmitter DAT 2015 IS is able to execute many functions such as : measure and linearisation of the temperature characteristic of RTDs sensors, conversion of a linear resistance variation, conversion of a voltage signal even coming from a potentiometer connected on its input. Moreover the DAT 2015 IS is able to measure and linearise the standard thermocouples with internal cold junction compensation. The measured values are converted in a 4+20 mA current signal. The device guarantees high accuracy and performances stability both in time and in temperature.

The programming of the DAT 2015 IS is made by a Personal Computer using the software PROSOFT, developed by DATEXEL, that runs under the operative system "Windows™". By use of PROSOFT, it is possible to configure the transmitter to interface it with the most used sensors

In case of sensors with a no-standard output characteristic, it is possible to execute, via software, a "Custom" linearisation (per step) to obtain an output linearised signal. For Resistance and RTDs sensors it is possible to program the cable compensation with 3 or 4 wires; for Thermocouples it is possible to program the Cold Junction Compensation (CJC) as internal or external.

It is possible to set the minimum and maximum values of input and output ranges in any point of the scale, keeping the minimum span shown in the table below. Moreover it is available the option of alarm for signal interruption (burn-out) that allows to set the output value as high or low out of scale

The DAT 2015 IS is in compliance with the Directive 2004/108/EC on the Electromagnetic Compatibility. It is housed in a plastic enclosure of 12.5 mm thickness suitable for DIN rail mounting in compliance with EN-50022 and EN-50035 standards.

USER INSTRUCTIONS.

The 4÷20 mA output signal is measurable in the power loop as shown in the section "Output/Power supply connections"; Rload is the input impedance of instruments on the current loop; to obtain a correct measure, the value of Rload will be calculated as function of the power supply value (see section "Technical specification - Load characteristic"). The input connections must be made as shown in the section "Input connections"

To configure, calibrate and install the transmitter refer to sections " DAT 2015 IS: configuration and calibration" and

In order to guarantee a correct and safe operation of the transmitter the following requirements must be strictly satisfied

1) The power supply voltage (intrinsically safe) applied between the terminals M and N must be included between

11 V and 30 Vdc values.

2) The maximum power supplied by the safety barrier must be not higher than 0.75 W.

Ex Data

Output / supply	•
Ui = 30 V	Uo = 6.2 V
Ii = 100 mA	lo = 100 mA
Pi = 0.75 W	Po = 500 mW
Li = 0.1 mH	Lo = 3.6 mH
Ci = 10 nF	Co = 5 uF

T6:-20 ÷ +55°C

T5: -20 ÷ +70°C T4: -20 ÷ +85°C ('HT' vers.)

TECHNICAL SPECIFICATIONS (Typical at 25 °C and in nominal conditions)

Input type	Min	Max	Min. span	
TC(*) CJC int./ext.				l
J	-200°C	1200°C	2 mV	l
K	-200°C	1370°C	2 mV	l
S R	-50°C -50°C	1760°C 1760°C	2 mV 2 mV	l
к В	400°C	1760 C 1820°C	2 mV	l
E	-200°C	1020°C	2 mV	l
T	-200°C	400°C	2 mV	l
N	-200°C	1300°C	2 mV	l
RTD(*) 2,3,4 wires				
Pt100	-200°C	850°C	50°C	l
Pt1000	-200°C	200°C	50°C	l
Ni100	-60°C	180°C	50°C	l
Ni1000	-60°C	150°C	50°C	
Voltage				l
mV	-100mV	+700mV	2 mV	l
Potentiometer				
(Nominal value)	0 Ω	200Ω	10%	l
,	200 Ω	500Ω	10%	l
	0.5 KΩ	2 ΚΩ	10%	l
RES. 2,3,4 wires				
Low	0 Ω	300Ω	10 Ω	l
High	0 Ω	2000 Ω	200 Ω	
Output type	Min	Max	Min. span	
Direct current	4 mA	20 mA	4 mA	
Reverse current	20 mA	4 mA	4 mA	l

Input calibration (1) RTD > of ±0.1% f.s. or ±0.2°C Low res. > of $\pm 0.1\%$ f.s. or $\pm 0.15~\Omega$ High res. > of $\pm 0.2\%$ f.s. or $\pm 1~\Omega$ > of $\pm 0.1\%$ f.s. or ± 18 uV mV. Tc **Output calibration** ±7uA

Input impedance

mV, Tc >= 10 MΩ

Linearity (1)

± 0.2 % f.s.

Tc

RTD +01%fs

Line resistance influence

<=0.8 uV/Ohm mV, Tc

RTD 3 wires $0.05\%/\Omega$ (50 Ω balanced max.) RTD 4 wires $0.005\%/\Omega$ (100 Ω balanced max.)

RTD excitation current

0.350 mA Typical

CJC comp. ± 0.5°C

Thermal drift (1)

± 0.01% / °C Full scale CJC ± 0.01% / °C

Burn-out values


about 22.5 mA Max. value Min. value about 3.6 mA

(1) referred to input Span (difference between max. and min. values)

Response time (10÷ 90%) about 400 ms Power supply

11 .. 30 Vdc Power supply voltage Reverse polarity protection 60 Vdc max

Load characteristic - Rload (maximum load value on current loop per power supply value)



Temperature & humidity Operative temperature -20°C .. +70°C 'HT' vers: -20°C .. +85°C

-40°C .. +85°C Storage temperature Humidity (not condensed) 0 .. 90 %

Housing

Self-extinguish plastic Material Mounting DIN rail in compliance with EN-50022 and EN-50035

Weight about 90 g.

EMC (for industrial environments)

FN 61000-6-2 Immunity **Emission** EN 61000-6-4

DAT 2015 IS: CONFIGURATION AND CALIBRATION

Warning: during these operations the device must always be powered by a safety barrier; to connect the interface Prodat, use the protection cable CVPR-03.

- CONFIGURATION

- 1) Power-on the DAT 2015 IS by a safety barrier (see Ex data).
- 2) Remove the protection plastic cap on DAT 2015 IS.
- 3) Connect the interface PRODAT to the Personal Computer and to device. using the protection cable CVPR-03. (see section "DAT 2015 IS: PROGRAMMING").
- 4) Run the software PROSOFT.
- 5) Set the parameters of configuration .
- 6) Program the device.

- CALIBRATION CONTROL


With software PROSOFT running:

- Connect on the input a calibrator setted with minimum and maximum values referred to the electric signal or to the temperature sensor to measure.
- 2) Set the calibrator at the minimum value.
- 3) Verify that the DAT 2015 IS provides on output the minimum setted value
- 4) Set the calibrator at the maximum value.
- $5 \overset{'}{)}$ Verify that the DAT 2015 IS provides on output the maximum setted value.
- 6) In case of regulation of value obtained in the step 3 and 5, use the ZERO and SPAN regulators of software PROSOFT.

The variation introduced from these regulators must be calculated as percentage of the input range

7) Program the device with the new parameters .

DAT 2015 IS: PROGRAMMING



INSTALLATION INSTRUCTIONS

In order to guarantee the safety requirements, before to install the device, refer to the "Safety Instructions" provided with the device.


The transmitter must be mounted in order to guarantee to it an IP54 protection grade or more for external environments and an IP4X protection grade or more for internal environments or protected area.

The device DAT 2015 IS is suitable for DIN rail mounting.


It is necessary to install the device in a place without vibrations; avoid to routing conductors near power signal cables .

DAT 2015 IS: CONNECTIONS

INPUT CONNECTIONS



OUTPUT/POWER SUPPLY CONNECTIONS



DIMENSIONS (mm) & CONNECTOR PGRM

